




User Manual

MTP7632 Kiosk Printer



Telpar

187 Crosby Road, Dover, NH 03820

800-872-4886

www.telpar.com

DECLARATION

This manual applies to MTP7632 series embedded printer, and the information in this document is subject to change without notice. If users need the further data about these products, please feel free to contact Telpar. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose without the express written permission of Telpar.

Copyright

Copyright © 2007



Warning

Items shall be strictly followed to avoid injury or damage to body and equipment



Notice

Items with important information and prompts for operating the printer



Heating

Calorific parts, don't touch.



Warning

Don't touch and avoid damage due to static electricity.

Revision History

Date	Version	Description
3-30-2007	V1.0	First version

Safety Instructions

Before installing and using the printer, please read the following items carefully

- 1) Install the printer at a flat and stable place.
- 2) Reserve adequate space around the printer so that the operation and maintenance can be performed conveniently.
- 3) Keep the printer far away from water source.
- 4) Do not use or store the printer in a place exposed to heat of fire, moisture and serious pollution and do not expose the printer to direct sunlight, strong light and heater.
- 5) Do not place the printer in a place exposed to vibration and impact.
- 6) No dew condensation is allowed with the printer. In case of such condensation, do not turn on the power until it has completely gone away.
- 7) Connect the AC power adapter to an appropriate grounding socket. Avoid sharing one electrical socket with large power motors and other devices that may cause the fluctuation of voltage.
- 8) Disconnect the DC adapter when the printer is deemed to idle for a long time.
- 9) Don't spill water or other electric materials into the printer. If this case happens, turn off the power immediately.
- 10) Do not allow the printer to print when there is no paper installed, otherwise the print head and platen roller will be damaged.
- 11) To ensure printing quality and products lifetime, use recommended paper or its equivalent.
- 12) Turn off the power when connecting or disconnecting interfaces connectors to avoid damages to control board.
- 13) Set the printing darkness in a lower grade as long as the print quality is acceptable. This will help to keep the print head durable.
- 14) Do not disassemble the printer without permission of a technician, even for repairing purpose.
- 15) Keep this manual carefully for reference.

CONTENT

1. SUMMARY	7
1.1 Brief introduction	7
1.2 Main features	7
2. MAIN TECHNICAL INDEX	9
2.1 Technical specification.....	9
2.2 Paper Specification.....	11
3. STRUCTURE AND FUNCTIONS.....	13
3.1 Appearance.....	13
3.2 External dimension.....	14
3.2.1 Overall size of the printer	14
3.2.2 Printing unit size	17
3.3 Print unit and controlling parts.....	17
3.3.1 Exterior of print unit and controlling parts.....	17
3.3.2 Print unit explanation	18
3.4 Presenter	19
3.5 Paper holder.....	20
3.6 Interface.....	21
4. INSTALLATION AND SUGGESTION	21
4.1 Unpacking.....	21
4.2 Adjusting paper near end sensor.....	21
4.2.1 Detection range of paper near end sensor.....	22
4.2.2 Adjusting paper near end sensor.....	23
4.3 Connecting the grounding wire.....	23
4.4 Connecting the AC power adapter.....	24
4.5 Connecting interface cable.....	24
4.6 Assembling and feeding paper roll.....	25
4.6.1 Assembling paper.....	25

4.6.2 Loading paper	26
4.7 Installing the printer	27
4.7.1 Installation notice	27
4.7.2 Keep space for printer installation.....	28
4.8 Installing printer driver.....	32
4.8.1 Typical installation	33
4.8.2 Advanced installation	35
4.8.3 USB printer driver	37
5. ROUTINE MAINTENANCES	40
5.1 Cleaning Print head	40
5.2 Cleaning sensor	41
5.2.1 Cleaning paper end sensor	41
5.2.2 Cleaning paper load sensor.....	44
5.2.3 Cleaning retraction sensor	45
5.2.4 Cleaning paper out sensor	46
5.3 Cleaning the platen.....	48
5.4 Manual resetting cutter	48
5.5 Manual removal of the jammed paper.....	49
5.6 Remove the jammed paper of presenter.....	49
6. INTERFACE SIGNAL.....	50
6.1 RS-232 Interface	50
6.1.1 Parameter	50
6.1.2 Interface linking terminal distribution and signal function	51
6.1.3 Demonstration of interface connection.....	51
6.2 IEEE1284 Parallel interface (optional)	51
6.2.1 Parameter	51
6.2.2 The influence of printer status to parallel interface.....	52
PE	52
6.2.3 Parallel interface signal	52
6.2.4 Time sequence of data receiving	53
6.3 USB interface (optional)	54

6.4 Power interface54

7. TROUBLESHOOTING AND MAINTENANCE.....55

7.1 Common errors and settlement55

7.2 Solution for common errors55

7.2.1 Problems during paper loading 56

7.2.2 Problems during printing 57

7.2.3 Problems during paper out 58

7.2.4 Other problems..... 58

8.0 WARRANTY59

APPENDIX60

Appendix 1 Self-test page.....60

Appendix 2 Tool software62

Appendix 2.1 EEPROM configuration software.....62

Appendix 2.2 Demo program62

1. Summary

1.1 Brief introduction

MTP7632 printer is a high performance thermal printer equipped with cutter and presenter, it can accept up to 254mm paper rolls. The maximum print width is 80mm. It can be widely used in various Kiosk applications like data communication terminal, test instrument terminal and outdoor information consulting terminal, etc.

MTP7632 consists of the following modules:

- Thermal printing unit
- Presenter (optional, or with paper-out path organ)
- Paper holder (optional, or without)
- Control board
- Cutter (optional, or without)

For different installation environments, MTP7632 has two modules for customers to select: the horizontal and vertical. MTP7632 can be connected with other device by parallel interface, or serial interface and USB interface.

Drivers are available for WINDOWS98/NT4.0//2000/XP/2003, Windows XP Embedded.

Note: NT operation system doesn't support USB interface.

1.2 Main features

- Printing
 - High-speed
 - Low-noise thermal printing
 - High reliability
- PRESENTER
 - Paper accommodation
 - Paper retraction
 - Holding paper
 - Paper out function
 - Paper ejection

Note:

- The Presenter is at the front end of the printer;
- Paper ejection and paper out function are not available on standard printer and only for customization.

- Applications
 - Command set is compatible with ESC/POS standard;
 - Characters handling: zoom 1 to 6 times horizontally or vertically, rotation print (0°, 90° , 180° , 270°),

black/white reverse, underline, upside-down print;

- Barcode print: print barcode by commands in horizon and vertical;
- Character size (Font A or Font B) can be set by commands;

- Printer maintenance

- Replace paper roll easily;
- Clean the print head conveniently
- Characteristics and parameters can be set by software;
- Auto-cut paper;
- Semi-auto paper load;
- Mark identification and checkout;
- Updating printer firmware on-line.

2. Main technical index

2.1 Technical specification

Items		Parameter	
		203dpi model	300dpi model
Printing	Print method	Direct thermal line	
	Resolution	203DPI	300DPI
	Paper width	82.5±0.5mm/79.5±0.5mm/76±0.5mm/69.5±0.5mm/57.5±0.5mm	
	Print width	Max.80mm (3.2")	Max.80mm (3.2")
		Max. 640 dots	Max. 944 dots
	Print height	Max: 450 mm	
		Min: 58 mm	
	Print speed	150 mm/s	100 mm/s
	RAM memory	SDRAM: 2MB	
	Flash memory	1MB/2MB/4MB	
	Print head temperature detect	Thermal resistor	
	Print head position detect	Micro switch	
	Paper/mark detect	Optical sensor	
Paper near end detect	Optical sensor		
Interface	RS-232, Centronics (optional), USB (optional)		
Barcode Fonts Graphics	Barcode	CODE128, ITF , UPC-A, UPC-E, EAN13 EAN8 , CODE39, CODE93, CODABAR, PDF417	
	Fonts	Standard ASCII, compressed ASCII Optional Asian character set (Simplified Chinese, traditional Chinese, Japanese, Korea)	
	Fonts Process	All fonts can be enlarged 1 to 6 times vertical and horizontal respectively, Rotation Print (0°, 90°, 180°, 270°) Bold, white/black reverse, underline	
	Graphics	Support BMP bit image download to RAM, FLASH and direct BMP print	
Medium	Paper type	Continuous paper/marked paper	
	Paper roll OD	Max.254mm	
	Paper roll ID	≥25.4mm	

Items		Parameter	
		203dpi model	300dpi model
	Thickness	60~100 um	
	Thermal layer	Outer side, inside	
Power	+24V power supply, room temperature , average value	2.5A (50%)	
PRESENTER	Paper out detection	Optical sensor	
	Paper out speed	400 mm/s	
	Retraction detect	Optical sensor	
	Paper retracting speed	400 mm/s	
	Paper out modes	Retraction /Ejection/holding /close/high speed presenting (optional) Note: holding paper or presenting paper at high speed is customized.	
Reliability	Print head lifetime	≥100 Km	
	Cutter lifetime	≥1,000,000 cuts (65um thermal paper)	
	MTBF	37,000,000 lines (Feed paper)	
Environment	Operation environment	Temperature: 5~45□ Humidity: 20-90%RH (40□)	
	Storage environment	Temperature: -40~60□ Humidity: 20 to 93% RH (40□)	
Physics character	Overall size	1. With standard horizontal paper holder: 431.4(L) X 164.4(W) X 203(H) 2. Compatible with BK-W080 vertical paper holder: 262.5(L) X 190(W) X 370.8(H) 3. Compatible with BK-W080 horizontal paper holder: 328.4(L) X 147.7(W) X 167(H)	
	Weight	About 4Kg (without paper roll)	

Table 2.1 Technical specification

Note:

- 1) DPI: dots printed for each inch. (One inch is about 25.4mm)
- 2) The real print speed is related with data transmission speed, speed darkness, print duty, control commands and input voltage, which may be lower than that in above table.
- 3) PRESENTER is a mechanism accommodating paper, and lies at the front of the printer.

2.2 Paper Specification

- Paper type: Continuous /marked thermal paper
- Paper supply method: Paper roll
- Paper width: 82.5±0.5mm/79.5±0.5mm/
76±0.5mm/69.5±0.5mm/57.5±0.5mm
- Paper thickness: 60um-100um
- Thermal layer: Outer side of the roll
- Paper roll specification: Roll inner diameter: 25.4mm or
≥50mm
- Max. paper roll outer diameter: ϕ 254mm

Note:

1. The weight shaft is a part of MTP7632 of which the assembly mostly depends on the paper specification;
2. The ticket width that MTP7632 can be suitable for is related with the paper specification greatly as below:

Paper thickness	Thermal side	Need weight shaft or not	Suitable for ticket length
60—100g/m ²	Outer side	Need	58-450mm
60g/m ²	Inside	No need	58-220mm
80-100g/m ²	Inside	Need	58-450mm

Table 2.2-2 Weight shaft and paper

➤ Marked paper specification:

Marked paper should meet the following requirement besides that of standard paper:

1. Mark position
 - ✓ For the marked paper over 79 mm width, you can select thermal layer/non-thermal layer left, middle and right (six positions) as shown in Table 2.2-1. Ensure beside marks cover mark sensor completely (The space between mark sensor and the paper midline is 38.2 mm);
 - ✓ For paper mark less than 79 mm width, you can select thermal layer/non-thermal layer middle (two positions). Ensure the mark midline to stand on the paper midline;
 2. In using marks, it is recommended to use the following parameter:
 - ✓ L1 mark width: $8\text{mm} \leq L1 \leq \text{paper width}$
 - ✓ L2 mark width: $4\text{mm} \leq L2 \leq 8\text{mm}$
 3. The reflectivity of marks is less than 10%; The reflectivity of other part of the ticket within mark width along paper feed direction is over 75%. There should not be any characters, graphics as advertisement between marks space.
- **Reflectivity:** Marked part should lie in the back of thermal layer, the reflectivity of black mark is less than

15%, and other parts reflectivity is more than 75%, area between marks should not have any figures, such as advertisements.




Figure 2.2-1 Marked position

Note:

- ✧ Because of paper shaking in the feeding and paper difference, the position fixed by mark may have an error of $\pm 1\text{mm}$;
- ✧ To adjust the printer configuration can set the mark length;
- ✧ Three sensor positions have been designed in paper path. The printer when out of factory is only assembled with one sensor and default position is in the middle of the paper path;



Notice:

- Please use the recommended paper or its equivalents. Using other types of paper may affect print quality and reduce the print head lifetime.
- Do not paste the paper to the shaft core.
- If the paper comes in contact with chemical or oil, it may discolor or be less heat sensitive, which will greatly affect the print quality.
- Do not rub the paper surface with a nail or hard metal. Otherwise it may discolor.
- When the temperature goes up to 70 degrees, paper will discolor. So please be careful to the effect of temperature、humidity and sunlight in environment.

3. Structure and functions

3.1 Appearance




Fig.3.1-1 MTP7632 printer exterior

- | | | |
|---------------------------|----------------------|--------------------------|
| 1—Horizontal paper holder | 2 —Paper roll shaft | 3 —Paper near end sensor |
| 4 —Keypad | 5 —Circuit board box | 6 —Power switch |
| 7 —Mechanism | 8 —Product label | 9 —PRESENTER |
| 10 —Paper feed label | 11 —Buffer shaft | 12 —Bottom plate |
| 13 —Spanner | 14 —Spanner label | |

Note:

This manual introduces the exterior of the printer with standard horizontal holder of which the control board is put on the right (feed paper on the left).

3.2 External dimension

3.2.1 Overall size of the printer




Figure3.2-1 Print size with standard horizontal paper holder
(Load paper on the left)




Fig. 3.2-2 The printer size compatible with MTP7632 horizontal paper holder




Fig. 3.2-3 Printer size compatible with MTP7632 vertical paper holder




Fig.3.3-1 Print unit and controlling parts

1 —Print unit tip board	2 —Spanner	3 —Auto. cutter
4 —PRESENTER	5 —Power switch	6 —Cut button
7 —Feed button	8 —Reset button	9 —Paper LED
10 —Error LED	11 —Power LED	12 —USB interface
13 —RS-232	14 —Power socket	15 —Paper inlet

Note: Take the left-paper-feed structure as an example to explain the exterior.

3.3.2 Print unit explanation

- 1) **Spanner:** After turning over PRESENTER, the spanner could be pressed down to separate the platen from the print head so that some errors could be removed;
- 2) **Power switch:** Press “0” to turn off the power, or press “—”to turn on the power;
- 3) **CUT button:** Press this button to cut paper under any status (even if the printer alarm or not).
- 4) **FEED button:**
 - If the printer doesn’t alarm, press down this button to feed paper;
 - If need to feed long paper, this button could be pressed constantly;
 - After pressing FEED button and turn on the power for 1s, the printer shall start and print a self-test page of which the printout could be changed with the printer configuration.

Note: Make sure that there is paper in the printer and the print head is not uplifted before starting self test (for self test page, please refer to [Appendix 1 Printer self test page](#))

- 5) **Reset button:** When pressing down this button, the printer shall execute its reset and the print data shall be cleared;
- 6) **Paper LED (Red):** When detecting paper end or paper near end, paper LED shall light always. If the paper is normal, paper LED shall not be on;
- 7) **Error LED: (Red)** Indicate different status of the printer. Normally, it is not light; when errors happen (for example, paper end), it will flash to give alarms.
- 8) **Power LED: (Green)** Indicate whether the power is on and it lights all the time when the power is turned on.



Heating

- ✧ **Print head:** The Print head are calorific in use; please don’t touch it just after operation.

3.4 Presenter




Fig. 3.4-1 PRESENTER exterior

1. Presenter tip-board
2. Presenter turnplate
3. Presenter weight shaft: This shaft is provided as a part. User can decide whether this shaft could be assembled depending on the paper type used. The paper details is referred to Table 2.2 Paper specification;
4. Paper top cover
5. Paper outlet
6. Paper load sensor: When proceeding paper load, ensure paper Auto-load depending on the position detected by paper load sensor;
7. Paper out sensor: Check the print paper status to confirm whether the paper is taken away;
8. Retraction sensor: Check whether the paper is retracted properly in paper retraction.



Notice

- Do not place the presenter module in a place exposed to direct sunshine. Otherwise paper out sensor will become ineffective.
- If paper jammed, please open the presenter top cover and remove jammed paper.

3.5 Paper holder




Fig. 3.5-1 Paper holder exterior

1. Paper holder supporting board: can be turned over for easy paper load;
2. Spanner label: indicate the force direction when starting the spanner;
3. Spanner: Through pulling up the spanner, the paper holder could be turned aside;
4. Paper roll axis
5. Paper near end sensor: check whether the test paper roll shall be used out;
6. Hand screw: connect paper axis onto the paper roll holder;
7. Paper roll buffer handle
8. Paper roll buffer shaft: The paper entering the print unit could be buffered through this shaft fixed onto the buffer handle;
9. Pedestal

3.6 Interface




Fig.3.6-1 USB interface printer

Fig.3.6-2 Centronics printer

- 1 —Power socket
3 —USB interface

- 2 —RS-232 interface
4 —Centronics



Notice: Can configure only Centronics or USB.

4. Installation and suggestion

4.1 Unpacking

Open the carton and check whether all items listed on the packing list are included or have any damages. In case of damages or missing items, please contact your dealer or the manufacture for assistance.



Notice:

- Decide whether Presenter weight shaft could be assembled according to the paper type used. The details are referred to Table 2.2 Paper specification.

4.2 Adjusting paper near end sensor

The printer has been assembled completely in the packaging, but the paper near end sensor should be adjusted before the printer put into use.

4.2.1 Detection range of paper near end sensor

The detecting result of remaining paper can be changed with I/O and D/O of paper roll core shaft. The Mini. amount of remaining paper can be calculated in theory as below:

Paper thickness (μm)	Paper roll I/O (A) : $\phi 25.4\text{mm}$; D/O (B) : $\phi 32\text{mm}$	
	Mini. detecting diameter(C)/length	Max. detecting diameter(C)/length
60	$\phi 39\text{mm}/3.8\text{m}$	$\phi 65\text{mm}/38.7\text{m}$
	Mini. detecting diameter(C)/length	Mini. detecting diameter(C)/length
80	$\phi 39\text{mm}/2.8\text{m}$	$\phi 65\text{mm}/29.4\text{m}$

Table 4.2-1 Mini. estimating amount of remaining paper




Fig. 4.2-1 Paper roll




Fig. 4.2-2 Mini detection of paper near end sensor




Fig. 4.2-3 Max. detection of paper near end sensor

4.2.2 Adjusting paper near end sensor

The default position of paper near end sensor when out of factory is the Mini. detection position (Referring to Fig. 4.2-2). If need the adjustment, the method is shown as below (Tool: cross screw driver)




Fig. 4.2-4 Adjustment of paper near end sensor

- Turn and loose two M3 screws with a screwdriver shown as Fig.4.2-4;
- Adjust it with a hand according to your requirement (see Fig. 4.2-4 paper near end sensor adjustment);
- When reaching the required detection position, tight the screw with the screwdriver;



Notice:

Mini. detecting amount of paper near end as above table is the theory value. There is a deviation in actual state.

4.3 Connecting the grounding wire

To ensure that the printer has a nice grounding status, please follow Fig. 4.3-1 to connecting the grounding

wire.

Tool needed: cross screwdriver

- Tighten the grounding wire to a grounding pole with one M3×5 pan head screw (see Fig. 4.3-1), then the grounding wire connection is finished;




Fig. 4.3-1 Grounding position


4.4 Connecting the AC power adapter

1. Make sure the printer is turned off.
2. With the flat side of cable pin of the cable pin into the power printer.

(see Fig. 4.4-1 connecting the AC power adapter)

3. Connect the AC power cable to an

Fig.



AC adapter facing downward, plug interface on the bottom of the

electrical outlet.

4.4-1 Power adapter connection



Notice:

- Use recommended power adapter or equivalent one;
- Connect power adapter connector at right angle between pin and socket.
- When connecting or disconnecting the cable connector of the AC adapter, always hold the connector shell and don't pull the cable forcibly.
- Avoid dragging or pulling the cable of AC adapter, otherwise the cable may be damaged or broken, and a fire and electric shocking may be caused accordingly.
- Avoid placing the power adapter near an overheating device, otherwise the surface of cable may melt and cause a fire or electric shock.
- If leaving the printer idle for a long time, please disconnect the power of AC adapter of printer.

4.5 Connecting interface cable

1. Make sure that the printer has been shut down, (sign "O" in power switch is pressed down);

2. Connect the series interface cable, parallel interface cable and USB cable into a relevant interface of the printer, and fix them with screws or spanner springs (see figure 4.5-1,4.6-2,4.7-3);
3. Connect the other end of the interface cable to the host computer.




Fig.4.5-1 Serial connection Fig.4.5-2 USB cable connection Fig.4.5-3 Parallel connection

**Notice:**

- Make sure the interface cable is connected in correct direction.
- After connecting interface cable, tighten the screws on the both sides of serial interface; for parallel interface cable, make sure to tighten the spanner springs on both sides.
- When connect or disconnect the interface cable, make sure to hold the plug shell instead of dragging the cable forcibly.

4.6 Assembling and feeding paper roll

Before starting to load the paper roll, make sure the specification of paper roll is conformity with printer requirements (refer to [2.2 Paper specification](#)).

4.6.1 Assembling paper

- Lift up the spanner according to the label arrow and turn over the paper holder side board shown as below:




Fig.4.6-1 Turning the paper roll holder side board

- Shown as in Fig. 4.6-2, load the paper roll onto the core shaft and push it to the inner side of this core shaft, then remove the paper roll holder side board to its previous position;




Fig. 4.6-2 Load paper roll



Notice:

- Make sure that the paper roll with the thermal layer upward;
- Avoid hurting your fingers while loading paper.

4.6.2 Loading paper

Before loading paper, please confirming the front end of the paper meets with the requirements. (see figure 4.6-3)



Fig.4.6-3 Paper required

- Semi-automatic paper load
 - Turn on the power and the buzzer sounds for paper end;

- Shown as in Fig.4.6-4, let the paper head around the buffer shaft and put it on the incline outside of paper inlet, then press the paper head and push it into the paper inlet slightly according to the arrow for certain distance. When the platen starts to turn and hold the paper, release your hand;




Fig.4.6-4 Semi-automatic paper load

- The printer starts to load paper. The paper head shall stop at the normal print position until paper load is ended. The printer is ready for the print job;

**Notice:**

- Confirm that the thermal sensitive surface is above (see [figure 4.6-4A](#)), insure the printer prints correctly.
- When push the paper into the feeding path, please energize uniformity, confirm the front head of paper paralleled the feeding paper path, avoid paper deflecting upwards.

4.7 Installing the printer

MTP7632 embedded printing unit features easy and reliability operation, and it has good adaptability of installing and good maintenance. Module design, active connection, embedded character, flexible maintenance station; please refer to the content of this section in complete printer design, to insure MTP7632 embedded printing unit can work more credibility and availability.

4.7.1 Installation notice

1. Install the printer on a flat and stable surface. Recommend to use horizontal installation, the inclination angle shouldn't exceed $\pm 15^\circ$ (paper feeding direction) . Inclination in other directions is strictly forbidden.
2. Keep the printer far away from water source.
3. Do not place the printer in an area exposed to vibration and impact.

4.7.2 Keep space for printer installation

- Reserve space sketch

Refer to the dimension as below in the design for reserving spaces (see Fig. 4.7-1 and Fig.4.7-2 MTP7632 structure space)




Fig. 4.7-1 MTP7632 space with standard paper holder




Fig. 4.7-2 Structure space compatible with MTP7632 vertical holder

- **All spaces explanation**

- ◇ **Paper roll space**

When a complete printer runs normally, maximum space should be reserved for the paper roll;

- ◇ **Waste ticket retraction space**

The space is used for the tickets which shall be taken away;

- ◇ **Connecting cable space**

The connection places of communication cable and power cable need spaces;

- ◇ **Button spaces**

The spaces are used to execute cutter button, paper feed button and power switch operation;

- ◇ **Paper outlet**

After the printing, the paper should be out and a reception device could be set outside of the paper outlet. The paper outlet position sees Figure as below. Users can design the corresponding reception device by themselves;




Fig. 4.7-3 Paper outlet position

- ◇ **PRESENTER turning spaces**

They are a group of spaces relating to Presenter. Presenter could operate shown as below Fig.:




Fig. 4.7-4 Presenter spaces for operation

1. Shown as “1” item in the Fig. above: Presenter could accommodate paper shortly in the printing so that paper shall stick up as “1” item in the Figure. Here enough space should be reserved (the height is at least 100mm) to ensure paper presenting smoothly.
 2. Shown as “2” item in the Fig. above: After Presenter finishes the printing, the paper which is not needed shall retract shown as “2” item in the Fig. above. Therefore enough space should be reserved and waste collection device is designed to keep the retracted paper. (The size is shown in Fig.4.7-2);
 3. Shown as “3” item in Fig. above: When the paper is jammed at Presenter, the user needs to turn up the top cover at the front of Presenter to take out the jammed paper. Here enough space should be reserved in order to turn up the top cove and for users’ operation;
 4. Shown as “4” item in the Fig. above: To remove the paper jam at the platen and turn up the whole Presenter, here enough operation space should be reserved;
- ◇ Paper holder turning space and paper load space: The paper load mode used on MTP7632 printer is that first one side of paper holder is turned shown as Fig. above, then recover the paper holder position after loading paper roll on the paper shaft. Note: According to users’ requirement, the paper holder can be adjusted so that paper holder turns to the left or to the right by changing the configuration in paper load. The paper holder can turn to only one side for one user configuration.




Fig. 4.7-5 Paper holder turn to the right




Fig. 4.7-6 Paper holder turn to the left

- ◇ Paper load space: Because the paper is required round the buffer shaft in loading paper, it is needed that corresponding paper load space should be reserved at the printer side.

● Notice for paper holder self-design

It is better to install the printer with its paper holder. If the paper holder needs to be designed, users should pay attention to the items as below in the design:

- ◇ For installation dimension, please refer to [3.2 External dimension](#);
- ◇ Keep paper path expedite, avoid sharp folder to cause overload.
- ◇ Avoid that paper rubs with sharp object, in order to prevent paper thermal layer damaged.
- ◇ Make sure that paper keeps certain pressure to printer elastic shaft to get buffer effect.
- ◇ Make sure that paper center is in consistent with the center of the paper-feeding path, prevent paper going to one side during printing.
- ◇ If you need paper near end sensor, you should prolong the connecting wire of paper near end sensor, and pay attention to the position of connection wire, do not affect the feeding paper path.
- ◇ Make sure that paper holder has enough intensity, and make sure the paper shaft parallel with print head and cutter etc., avoid paper twisting in operation.

● The design of external paper out path

In your system, it may be necessary to make paper out path matching with the printer. To make sure paper out is smooth, we suggest that you design your paper out path as follows by different paper out mode.

- 1). When you adopting paper holding or paper backing for paper out mode, please refer to figure 4.7-7 Paper out interface 1

● Note:

1. Adopting funnel design for paper out path board, refer to the above figure, the recommend parameter as follows (paper outlet is the benchmark)




Figure 4.7-7 Paper out interface 1

- ◆ $a \leq 2\text{mm}$ (notice: reserve PRE upper cover turning space)
- ◆ $b \geq 6\text{mm}$
- ◆ $c \geq 5\text{mm}$
- ◆ $d \leq 1\text{mm}$

2. When designing paper outlet upper board, the bending angle should avoid paper hitting the path, the bending board should accord with the direction of the paper or keep $\pm 10^\circ$ obliquity.
3. The paper outlet shown in figure is just a sketch map; the paper outlet angle can be designed according

to actual need. But try to avoid the bend angle of paper outlet is not too big in order to increase the smoothness of the paper path.

- Avoid paper go through too long alleyway and decrease resistance to paper in order to paper out effectively (namely the paper can spitting out effectively) when the printer spitting the paper. Please refer to the figure 4.7-8 Paper out interface 2.




Figure 4.7-8 Paper out interface 2

Note:

- Adopting funnel designing for paper outlet board, refer to the figure above, the parameters are recommended as follows (the benchmark is the paper outlet) :
 - ◆ $a \leq 2\text{mm}$ (notice: observe PRE upper cover turning space)
 - ◆ $b \geq 8\text{mm}$
 - ◆ $c \geq 10\text{mm}$
 - ◆ $d \leq 1\text{mm}$
- For the paper go out effectively, the path designing should avoid baffling paper going forward and avoid path hitting paper; when designing upper path board, the bending angle should avoid the paper hitting the path, the bending board should accord with the direction of paper or keep $\pm 5^\circ$ obliquity;
- To avoid the path supporting ticket and the ticket can't fall off , the outlet nether board should incline downwards, we advise, the angle of incline $<$ the bending angle of paper -10° ;
- When adopting presenter, make sure its deepness greater than the longest ticket, the recommended deepness is: the longest ticket + 50mm;
- The above contents is only the reference, you can adjust it according to the actual operation.

4.8 Installing printer driver

MTP7632 printer offers the driver supporting the operation systems as Windows 98/Windows NT4.0/Windows 2000/ Windows XP/ Windows server 2003. The English software package: Setup_BK-T080_EN

V1.01. The installation includes typical mode and super mode.


4.8.1 Typical installation

Installation steps are shown as below:


- First run Setup.exe in “ Setup_BK-T080_EN V1.01”, then read the relative software license protocols. If you accept all the clauses, click “I Accept” and “Next” button;



- Choose the printer type and name to be installed. If you set this printer as a default in the system, choose the button “Set As Default Printer”, then click “Next”;



- Select the installation mode: “Typical” and click “Next”;



- The driver identifies the current system type, then click “Next”;



- Set the printer port and the system default “LPT1” as the print port. Users should choose the installing port according to its use. Under windows NT4.0 or above, select “BYCOMx” as Serial driver(X equals to 1, 2, 3,4, 5, 6, 7 or 8), then click “Finish” to end the installation;




- In the system of Windows 98/Me, click “Yes” in pop-up dialog box and restart the PC;

4.8.2 Advanced installation

Super installation is mainly used for the users who have special request to the printer driver. It adds the functions which support several USB printers’ driver and set the driving mode with the steps as below:


- Run Setup.exe in the file “Setup_BK-T080_EN V1.01”. then read the relative software license protocols. If you accept all the clauses, click “I Accept” and “Next” button;




- Choose the printer type and name to be installed (take BK-T0802 as an example). If you want to set the printer as a default, choose “Set As Default Printer”;




- Choose the installation: “Advanced” and click “Next”;



- The driver identifies the current system type, then click “Next”;



- Set the printer driving mode and print port. The system defaults “LPT1” as the print port and supports several USB installation, then click “Finish” to end the installation;



- In window 98/Me, click “Yes” in the pop-up dialog box to restart the PC;

4.8.3 USB printer driver

USB printer driver is installed with two steps: 1. USB driver device installation; 2. Printer driver installation;

Step 1: USB device driver installation

Windows 98/Me

- Connect one USB printer to the host and insert USB connecting line to the idle USB interface of the host. The system could find USB device and pop up the driver installation guide. Then click “Next” to enter USB device driver installation;
- Choose “Search Device Latest Drive” and click “Next”;
- Select “Specified Position” and click “Browse” button. Search the driver through this Browse. The default is : Setup_BK-T080_EN V1.01\USBDREV2.20, then click “Next”;
- The guide shows that the device driver name is found, then click “Next”;
- Click “Finish” to end the installation;

Windows 2000


- Connect one USB printer to the host and insert USB connecting line to the idle USB interface of the host. The system could find USB device and pop up the driver installation guide. Then click “Next” to enter USB device driver installation;
- Select “Search Suitable Device Driver” and click “Next”;
- Select “Specific location” and click “Next”;
- Click “Browse” button and search for the driver through it. The default is Setup_BK-T080_EN V1.01\USBDREV2.20;
- The guide shows that the device driver name is found and click “Next”;
- Click “Yes” on the digital signature page;
- Click “Finish” to end the installation;

Windows XP


- Connect one USB printer to the host and insert USB connecting line to the idle USB interface of the host. The system could find USB device and pop up the drive installation guide. Select “Install from a list or specific location” and click “Next”;



- Select “Search for the best driver in these location”, also select “Include this location in the search”, then click “Browse...” Search the driver through the browse, the default is Setup_BK-T080_EN V1.01\USBDREV2.20, then click “Next”;



- Click “Continue Anyway” on the digital signature page;



- Click “Finish” to end the installation;



Windows Server 2003

- Connect one USB printer to the host, and insert USB connecting line to the idle USB of the host. The system could find USB device and pop up the driver installation guide. "Install from a list or specific location" and click "Next";
- Select "Search for the best driver in these locations", also select "Include this location in the search", then click "Browse..." Search the driver through the browse, the default is Setup_BK-T080_EN V1.01\USBDREV2.20, then click "Next";
- Click "Continue Anyway" on the digital signature page;
- Click "Finish" to end the installation;

In the systems of Windows XP and Windows Server 2003, when other USB interfaces of the host is connected to USB printer for the first time, pop up a driver installation guide after identifying USB device. If the system has been installed USB device driver once according to the steps above, select "Auto. install software" in the installation guide, then click "Next". The guide can search the driver automatically. A digital signature page shall pop up after finding the device, then click "Still continue". When the installation is finished, click "Finish" to end it;

Step 2: Printer driver installation

Connect one printer to the host, and then install the driver. Refer to Typical Installation and Advanced Installation.

5. Routine maintenances



Caution:

- Before starting routine maintenance for the printer, make sure the power is turned off.
- Do not touch the surface of print head with hands or metal. Do not use forceps so as to prevent print head, platen roller and sensors being scratched.
- Do not use organic solvent like gasoline, acetone and etc.
- When cleaning print head or sensors, please wait for pure alcohol to evaporate totally before starting printing.
- It is recommended to do routine maintenance per month.

5.1 Cleaning Print head

When the following cases occur, the print head should be cleaned.

- Printout is not clear;
- Some columns on the page are not clear;
- Paper feeds or retracts with big noises.

Cleaning steps as follows:

1. Turn off the printer power.
2. Referring Fig.5.1-1, hold the front end of Presenter with hands and pull it forcibly according to the arrow shown in the Fig. below so that Presenter could turn to the position as in Fig.5.1-2;




Fig. 5.1-1 Cleaning the Print head

3. Press the spanner slightly with a finger according to the red arrow shown in Fig.5.1-2 until the platen is away from the cutter unit;




Fig. 5.1-2 Cleaning the Print head

4. Shown as in Fig.5.1-3, now you can view the printer from the downside of the print mechanism and find the Print head in the behind of the moving blade. Clean the Print head surface with alcohol cotton which should be twisted before the use;




Fig. 5.1-3 Cleaning the Print head

5. After the Print head is dry, execute the assembly according to the reverse steps. Then check the connecting cable and start the power after ensuring the correct connection;

5.2 Cleaning sensor

5.2.1 Cleaning paper end sensor

When the following cases occur, the Print head should be cleaned:

- During printing, the printer sometimes stops printing and alarms paper end when there is paper in fact.
- The printer doesn't alarm paper end when paper is end.
- The printer doesn't identify marks correctly.

Cleaning steps for paper end sensor:

1. Turn off the power.
2. Screw down one M3-4 screw shown in Fig.5.2-1 with a cross screw driver and dismantle the lines protection board shown in Fig.5.2-1;




Fig. 5.2-1 Cleaning paper end sensor

3. Screw down two M2.5-4 pan head bolts(see item 1 in Fig. 5.2-2) with a cross screw driver, and dismantle the cover from the print motor shown as in Fig.5.2-2;




Fig. 5.2-2 Cleaning paper end sensor

4. Shown as in Fig.5.2-3, hold the Presenter shown in item1 with hands and pull it forcibly according to the arrow shown in the Figure below until the Presenter turns to the position shown in item 2 of the Figure below;




Fig. 5.2-3 Cleaning paper end sensor




Fig. 5.2-4 Cleaning paper end sensor

5. Pull out the print line from the Print head socket;
6. Screw down four M3-4 screws shown as in Fig.5.2-4 with a cross screw driver, then lift up the print module and take it away shown as in Fig.5.2-5;




Fig. 5.2-5 Clean paper end sensor

7. When you turn the spanner according to the red arrow shown in Fig.5.2-6, the mark sensor could be viewed. Use a cross screw driver to screw down the M2 screw on the sensor so that you can take off the mark sensor;




Fig. 5.2-6 Cleaning paper end sensor

8. Wipe off the dust or stains on the sensor with soft cotton cloth dipped with pure ethanol. After waiting for 5 to 10 minutes until 100% ethanol volatilizes completely, finish the assembly according to the reverse steps. Then check the connecting cable which should be proper and turn on the power;

5.2.2 Cleaning paper load sensor

When any of the following case occurs, paper load sensor should be cleaned.

- The paper can't back to normal printing position during automatic paper load.
- Print motor reverse backward for long time during automatic paper load.
- After printing is finished, the paper can't return to normal printing position.

To clean paper load sensors, following the steps given below:

1. Turn off the power;
2. Force on the direction shown in Fig.5.2-7 until PRE top cover is turned and open;
3. Then you can view the paper sensor in PRESENTER path. With soft cotton cloth dipped with pure alcohol (should be wrung) , wipe off dust and stains on the sensor surface.




Fig.5.2-7 Cleaning paper load sensor




Fig.5.2-8 Clean paper load sensor

4. Wait for 5–10 minutes until pure alcohol evaporates totally, and close PRE top cover according to the reverse steps, then turn on the power;

5.2.3 Cleaning retraction sensor

When the printer happens that Presenter fails to transmit paper retraction information properly, the retraction sensor should be cleaned;

To clean paper retraction sensor, follow the steps given below:

1. Turn off the power;
2. Shown as in Fig.5.2-9, you can view the retraction sensor at the retraction path of PRESENTER. Wipe away the dust and stains on the sensor surface in using cotton swabs (twisted) dipped with pure alcohol;




Fig.5.2-9 Cleaning retraction sensor

3. After waiting for 5–10 minutes until pure alcohol evaporates totally, turn on the power;

5.2.4 Cleaning paper out sensor


When any of the following case occurs, paper out sensor should be cleaned.

- Presenter fails to hold the paper properly;
- After Presenter holds the paper, it fails to retract paper;

To clean paper out sensor, follow the steps given below:

- Turn off the power;
- Shown as in Fig.5.2-7, turn and open PRE top cover;

Retraction sensor



- Now you can see paper out sensor in the path of PRESENTER. Swipe the dust and stains on the sensor surface by cotton swabs dipped with pure alcohol (twisted);




Fig.5.2-10 Cleaning paper out sensor

- After waiting for 5–10 minutes until pure alcohol evaporates totally, close PRESENTER upper cover in reverse steps and turn on the power.

5.3 Cleaning the platen

When any of the following case occurs, the platen should be cleaned.

- Print out is not clear;
- Some columns on the page are not clear.
- Paper feeds or retracts with big noises.

To cleaning printing platen roller, follow the steps given below:

1. Turn off the power;
2. Wait for a few minutes until print head cools down if the printer has just finished printing;
3. Refer to the 2~4 steps in [5.1 cleaning print head](#), you can see the platen;
4. Wipe off the dust and strains on the platen surface in using cotton cloth dipped with neutrality cleanser (should be wrung);
5. After the platen roller is dry, recover the printer according to the reverse steps and turn on the power.

5.4 Manual resetting cutter

When one of the following cases occurs, should reset cutter unit manually:

- The cutter can't cut off the paper, it doesn't go to home position; when pressing CUT button, the cutter doesn't act.
- Paper jams because the cutter doesn't go to home position. Press CUT button, but cutter doesn't act.

Tool needed: small cross screw driver

Reset cutter manually in the following steps:

1. Turn off the printer power;
2. Use the cross screwdriver to go through the hole as figure 5.4-1 and go forward to the cutter motor turbo, rotate the screwdriver along the arrow lightly , until there is big gap between upper and nether blade;




Fig.5.4-1 Manual cutter reset

5.5 Manual removal of the jammed paper

When any of the following errors occurs, please remove jammed paper manually.

- Paper jams between platen roller and cutter holder.
- Paper accumulates at paper inlet of the cutter in the front of print head.
- The cutter can't cut off paper.

Remove jammed paper in the following steps:

1. Turn off the printer power.
2. Referring to step 2 to 3 in 5.1, separate the platen from the Print head;
3. Check whether there is wastepaper under the cutter blade and Print head. If so, please take it out;
4. When confirming there is no wastepaper, recover the spanner and close the Presenter;
5. Turn on the power, and press down the CUT button, check whether the cutter can operate normally. If it can't, please refer to [5.4 Cutter manual resetting](#), complete the cutter resetting.



Notice:

- Turn off the power before you remove the jammed paper.

5.6 Remove the jammed paper of presenter

When any of the following errors occurs, please remove the paper manually:

- paper is jammed into the path of presenter;
- paper enlace on the platen roller of the presenter;
- paper does not enter into paper out path of presenter;

Remove jammed paper in the following steps:

1. When uplifting the PRE upper cover along the arrow direction

(refer to Fig.5.2-7) , the path of presenter open completely;

2. Take out the jammed paper.

6. Interface signal

6.1 RS-232 Interface

6.1.1 Parameter

- data transfer mode: asynchronous serial communication
- handshake mode: RTS/CTS control
- voltage level: MARK = -3 to -15 V: Logic "1"/ OFF
SPACE = +3 to +15 V: Logic "0"/ ON
- baud rate: 1200, 2400, 4800, 9600, 19200, 38400, 57600 bps
- data bit: 8 bit or 7 bit
- parity checkout: None, even, or odd
- stop bit: 1 bit
- connector: 9 pins serial connector (negative head)

Caution: Serial baud rate, data bit, parity bit are set by EEPROM

6.1.2 Interface linking terminal distribution and signal function

Printer signal and status is described as the following table:

PIN NO	Signal name	Signal direction	Function
1	NO		
2	RXD	Input	Data input end
3	TXD	Output	Data output end
4	DTR	Output	Data terminal is ready
5	SG	—	Signal ground
6	DSR	Hang	Data device is ready
7	RTS	Output	Request to send
8	CTS	Input	Allow to send
9	FG	—	Printer cover ground

Table 6.1-1 Interface and pin explanation

6.1.3 Demonstration of interface connection

Host side Printer side

TXD-----RXD

RXD-----TXD

DSR-----DTR

CTS-----RTS

RTS-----CTS

DTR-----DSR

FG -----FG

SG -----SG

Caution: Please make sure the printer is turned on and waiting for the end of initialization, then send data to the printer.

6.2 IEEE1284 Parallel interface (optional)

RS-232 serial interface is the standard interface of the printer, IEEE1284 parallel interface is the optional one, and works in compatible mode (For interface position, please refer to figure [3.6-2 Serial interface configuration](#)) .

6.2.1 Parameter

Data transfer: 8 bits parallel

Synchronization mode: nStrobe signal is provided by exterior

Handshake mode: Busy signal

Signal voltage level: TTL compatible

Connector: 36 pins inner empty type Centronics connector in accord with IEEE1284 agreement.

6.2.2 The influence of printer status to parallel interface

(/FAULT pin and PE pin)

Status	/FAULT	
Normal	High	Low
Paper end	Low	High
Print head overheated	Low	Low
Upper cover open	Low	Low
Cutter error	Low	Low

Table 6.2-1 /FAULT pin and PE pin explanation

When above errors occur, information can be got by reading the status of correlative pins of parallel interface.

6.2.3 Parallel interface signal

Pin No.	source	Compatible mode
1	H	nStrobe
2	H	Data 0 (Least Significant Bit)
3	H	Data 1
4	H	Data 2
5	H	Data 3
6	H	Data 4
7	H	Data 5
8	H	Data 6
9	H	Data 7 (Most Significant Bit)
10	P	nACK
11	P	Busy
12	P	Perror
13	P	Select
14	H	nAutoFd
15		Not Defined
16		Logic Ground
17		Chassis Ground
18	P	Peripheral Logic High
19		Signal Ground (nStrobe)
20		Signal Ground (Data 1)
21		Signal Ground (Data 2)
22		Signal Ground (Data 3)
23		Signal Ground (Data 4)
24		Signal Ground (Data 5)
25		Signal Ground (Data 6)
26		Signal Ground (Data 7)

Pin No.	source	Compatible mode
27		Signal Ground (Data 8)
28		Signal Ground (PErrror, Select, and nAck)
29		Signal Ground (Busy and nFault)
30		Signal Ground (nAutoFd, nSelctIn, and nInit)
31	H	nInit
32	P	nFault
33		Not defined
34		Not defined
35		Not defined
36	H	nSelectIn

Table 6.3-2 Parallel interface signal definition

Note: (1) H stands for host computer, P stands for printer terminal

- (2) Parallel interface signal use TTL voltage level. When it is used, please make sure both the rise and drop time of host computer terminal is not longer than 0.5 μ s.
- (3) When transmitting data, the host computer should not ignore the Busy signal, or else the print data may be lost.
- (4) The length of parallel interface connection wire should be as short as possible if it meets use requirement.

6.2.4 Time sequence of data receiving




Fig. 6.2-1 Time sequence of data receiving

Signal time demands:

signal	Min (ms)	Max (ms)
setup	0.75	-
ready	0	-
stb	0.75	500
busy	0	2.5
hold	0.75	-

Table 6.2-3 Explanation about interface signal

6.3 USB interface (optional)

RS-232 serial interface is the standard interface of the printer, and USB interface is an optional one which accords with USB 1.1 protocol standard, and work in full speed mode (For interface position, please refer to Fig.3.6-1 USB interface configuration model) . Data transfer bit rate is 12Mbps. USB transfers signal and power by a kind of four-line cable, D+ and D- connection wires in Fig. 6.3 are used to send signal.




Figure 6.3-1 USB Cable

6.4 Power interface

This connector is used to connect the printer with external power supply.

The pin distribution of power connector:

PIN	Signal name
1	+24V
2	GND
3	NC
SHELL	F.G.

Table 6.4 Power pin definition explanation




Figure 6.4-1 power supply

7. Troubleshooting and maintenance

If errors occur in the printer, consult the troubleshooting table below. If still can't settle the trouble, please contact with Telpar.

7.1 Common errors and settlement



Error	Description	Display mode of error LED 	Buzzer 	Recovery
Print head overheated	Temperature of print head is too high			If temperature is fallen, automatic recovering
Print head uplifting	Print head is uplifted			automatic recovering after put down the print head
Paper end	Paper sensor detects paper end			After reloading paper, automatic recovering
Cutter error paper jam	Paper jams or cutter can't work normally			Remove the jammed paper and press CUT key to cut paper

Table 7.1-1 Error index

Printer acts as follows when errors occur:

- Stop printing;
- Busy signal is available;
- Error LED glitters;
- The buzzer beeps.

7.2 Solution for common errors

7.2.1 Problems during paper loading

Problem	Possible reasons	How to settle
Paper roll can't be loaded into paper holder	The width and diameter of paper roll do not match the printer	Replace the paper
The printer can't feed paper automatically	Paper head is irregular; paper jams; The paper load sensor is not covered by paper head; dust and wastepaper covers the paper load sensor	Clear wastepaper according to requires; remove jammed paper; check the front head of paper to confirm that the paper load sensor is covered fully by paper; Clean the paper load sensor
The buzzer alarms	Paper end; the printer cover is not fully closed.	Replace the paper roll; Close Print head
After automatic paper feeding, the paper can't stop in the normal print position	Dust or wastepaper covers the paper load sensor	Clean the paper load sensor

Table 7.2-1 Errors in paper load

7.2.2 Problems during printing

Problems	Possible reasons	How to settle
The receipt can't be ejected out smoothly.	Paper jams	Check paper path, remove wastepaper and reload paper.
Printout is not clear	The paper is loaded in wrong direction or its quality is poor; print head needs cleaning; printing darkness is too low; input voltage is too low	Make sure the paper roll is loaded correctly; Use recommended paper or its equivalents; Clean the print head; Adjust print darkness (*) ; Use the power supply which meets requires
Cutter works abnormally	Paper jams in cutter; the cutter is broken	Check if there are sundries in cutter path(*); contact with TELPAR or your local distributor.
Printing data is lost and no printing	The print head does not closed; Paper jams.	Close printer upper cover properly; remove jammed paper

Table 7.2-2 Print problems

* To adjust print darkness, contact with Telpar.

* If paper jams in cutter, please remove the jammed paper first, and then press CUT button to reset the cutter.

7.2.3 Problems during paper out

Problems	Possible reasons	How to deal with
The printer stops printing and warns errors during printing	Paper is end; paper jams in cutter; dust or wastepaper covers the paper near end sensor.	Install a new paper roll Check if there are sundries in cutter path; clean the paper near end sensor.

Table 7.2-3 Problems in paper out

Note: Contaminated paper may cause detection failure.

7.2.4 Other problems

Problem	Possible reasons	How to settle
LED isn't light and printer doesn't work	The printer is not connected with the power correctly. The printer isn't turned on.	Connect the printer with the power correctly. Turn on the printer.
The printer doesn't work after receiving commands	Printer is in error status. The communication cable is not connected well. Interface setting is wrong.	Remove all errors (*) Make sure the communication cable is connected correctly. Print a self-test page and set the interface again according to information on it.

Table 7.2-4 Other problems

Note: Paper near end alarm acts only as a prompt for users, not error status. Therefore when this alarm is given, printing task can still be sent.

8.0 Warranty

TELPAR Printer Limited Warranty

For one (1) year after shipment of the printer product to Buyer, Telpar warrants the product against defects in materials and workmanship provided the product has been operated and maintained in accordance with manufacturer's operating and maintenance specifications. This warranty specifically excludes ribbons, paper and other consumable items.

THIS WARRANTY IS IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED. TELPAR MAKES NO OTHER WARRANTY AND BUYER SPECIFICALLY WAIVES ANY OTHER WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THERE ARE NO WARRANTIES THAT EXTEND BEYOND THOSE DESCRIBED HEREIN.

Telpar's liability hereunder is limited to the repair or replacement of defective parts. This liability does not extend to normal wear and tear. Telpar will, solely at its option, remedy all valid warranty claims either by:

- (a) Repairing or replacing the defective unit at Telpar's factory; or
- (b) Repairing or replacing the defective subassembly at Telpar's factory.

If so directed by Telpar, Buyer shall return the defective unit or subassembly, transportation prepaid by Buyer, to Telpar's factory. After repair or replacement has been accomplished, Telpar will return the unit or subassembly, transportation prepaid by Telpar, to Buyer.

As a precondition to any warranty service, prior to return of any units or subassemblies to Telpar by Buyer, Buyer must contact Telpar's Order Administration Services and receive authorization in the form of a Return Material Authorization (RMA) number. Telpar reserves the right to refuse any goods it has not previously authorized for return, or any goods shipped without transportation prepaid.

No warranty shall apply to any damage resulting from or caused by Buyer, if Buyer shall make any changes, modifications, additions or deletions of hardware, software or firmware in the Printer products sold hereunder without Telpar's advance written consent.

Warranty service may be obtained by contacting our Customer Service department for instructions:

To request a Return Material Authorization (RMA) Number:

Contact Telpar at 1 (800) 872-4886 to open a call for return products, repairs and warranty repairs.

For Telpar Warranty/RMA Service

Please provide Telpar with the following information:

- Serial number
- Model Number
- Contact name and phone number and email address
- Problem description
- The address where the equipment is to be shipped BACK to

Appendix

Appendix 1 Self-test page

Print self test page in the following steps: Turn off printer power, then press the FEED button for at least 1 second while turning on the printer. The printer will start to print a self-test page. (Take 203DPI/USB interface model for an example, and the self-test paper is shown as follows)

**** MPT 7632 TEST FORM ****

Boot Firmware:	FV1.010
Main Firmware:	FV1.000
H/W Parameters	
HW ID	MTP 7632 (U) 1
Flash Memory Size	1M bytes
Flash Logos Size	64k bytes
Resolution	203×203DPI
Valid Print Width (Max)	80mm
PrintSpeed (MAX)	150mm/s
Dark Scale	80
Cutter	Enabled
Presenter	Enabled
Presenter Mode	Retraction
Presenter Wait Time	3s
Comm Interface	
Rx Buffer Size	4K bytes
Interface Type	RS232
Baud Rate	38400bps
Data Bit	8
Stop Bit	1
Parity	NONE
Flow Control	RTS/CTS
Interface Type2	USB_BK-T0802_1
Command CR	Ignore
Resident Fonts	W×H
Standard Character	12X24
Compressed Character	9X17

Simplified Chinese	24X24
BarCode Available	UPC-A
	UPC-E
	EAN-8
	EAN-13
	CODE39
	CODE93
	ITF
	CODABAR
	CODE128

Explanation of self test page content:

Boot Firmware-----	Printer BOOTLOADER version
Main Firmware-----	Printer monitor program version
H/W Parameters-----	Printer parameter setting
H/W ID-----	Printer ID setting
Flash Memory Size-----	Printer FLASH capability
Flash Logos Size-----	Flash size for bitmap downloading
Resolution-----	Printer resolution
Valid Print Width (Max) ---	Maximum print width
PrintSpeed (MAX) -----	Print speed
Dark Scale-----	Print darkness
Cutter-----	Enable or disable auto cutter
Presenter-----	Enable or disable PRESENTER
Presenter Mode-----	PRESENTER paper out mode
PresenterWaitTime-----	PRESENTER waiting time before retracting or ejecting the printout
Comm Interface-----	communication interface setting
Rx Buffer Size-----	Data receiving buffer zone size
Interface Type-----	Interface type
Baud Rate-----	Serial communication baud rate setting
Data Bit-----	Serial communication data bit setting
Stop Bit-----	Serial communication stop bit setting
Parity-----	Serial communication verify bit setting
Flow Control-----	Serial communication data stream mode (handshaking mode)
Interface Type2-----	The second interface type
Command CR-----	Enable or disable CR command
Resident Fonts-----	Font setting
Standard Character -----	Standard character setting
Compressed Character -----	Compressed character setting
Simplified Chinese-----	Asia character setting
BarCode Available-----	Printable bar code model


Appendix 2 Tool software

For MTP7632 printer, we provide the following tools: EEPROM configuration software and Demo software. Their brief introduction is shown as follows:

Appendix 2.1 EEPROM configuration software

EEPROM configuration software is MTP7632 EEPROMSet, and its main function is to configure the printer. It is supported by WINDOWS98/NT4.0/2000/XP/Server 2003. The following is the main interface figure of MTP7632 EEPROMSet.

(For detailed use explanation, please refer to the help files in the tool software package)



Appendix 2.2 Demo program

The Demo program software is KIOSK Application, and it is mainly used to demonstrate the typical functions of the printer for users reference in using the printer. It supports the following system platforms: Windows2000/Windows XP/Windows Serve 2003. The following is the main interface figure of KIOSK Application: (For details, please refer to the help files in the tool software package)